






Asus F6A-X2 Screen for Hinges Replacement

Replacement guide on how to remove the screen from the hinges. Prerequisite-only.

Written By: Jonathan



Step 1 — Screen for Hinges



- Remove the six 2 mm Phillips #1 screws securing the hinges to the screen. There are three on each side.
- After the screws are removed, close the laptop and flip it over so it is face down.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-18 08:49:47 AM.